

































KEDAI MEBEL PRICELIST







NO	DESCRIPTION	PICTURE	CODE	SIZE (CENTIMETER)			MATERIAL	GRADE C	GRADE B	GRADE A
				W	D	H				
FACTORY PRICE OFFER										
1	TEAK DINING CHAIR		KMK 001	40	50	90	TEAK WOOD	\$ 61,89	\$ 86,43	\$ 94,59
2	TEAK DINING CHAIR		KMK 002	40	50	100	TEAK WOOD	\$ 68,42	\$ 93,74	\$ 101,17
3	TEAK DINING ARM CHAIR		KMK 003	50	55	100	TEAK WOOD	\$ 91,58	\$ 125,13	\$ 135,92
4	TEAK DINING CHAIR		KMK 004	50	55	100	TEAK WOOD	\$ 82,09	\$ 112,69	\$ 121,71
5	TEAK DINING CHAIR		KMK 005	40	50	90	TEAK WOOD	\$ 77,86	\$ 106,91	\$ 115,51
6	TEAK DINING ARM CHAIR		KMK 006	45	50	90	TEAK WOOD	\$ 94,43	\$ 130,89	\$ 143,56
7	TEAK DINING ARM CHAIR		KMK 007	50	55	105	TEAK WOOD	\$ 86,08	\$ 117,07	\$ 126,82
8	TEAK DINING CHAIR		KMK 008	40	45	110	TEAK WOOD	\$ 66,98	\$ 94,73	\$ 104,55
9	TEAK DINING CHAIR		KMK 009	50	55	105	TEAK WOOD	\$ 95,71	\$ 133,79	\$ 146,30
10	TEAK DINING ARM CHAIR		KMK 010	55	55	105	TEAK WOOD	\$ 108,98	\$ 152,39	\$ 167,90
11	TEAK DINING ARM CHAIR		KMK 011	45	50	95	TEAK WOOD	\$ 79,57	\$ 112,23	\$ 124,82













12	TEAK DINING CHAIR		KMK 012	40	50	95	TEAK WOOD	\$ 70,23	\$ 100,03	\$ 110,91
13	TEAK DINING ARM CHAIR		KMK 013	45	50	95	TEAK WOOD	\$ 92,67	\$ 127,81	\$ 139,71
14	TEAK DINING CHAIR		KMK 014	40	50	95	TEAK WOOD	\$ 83,33	\$ 115,61	\$ 125,80
15	TEAK DINING ARM CHAIR		KMK 015	45	50	95	TEAK WOOD	\$ 85,37	\$ 121,24	\$ 135,34
16	TEAK DINING CHAIR		KMK 016	40	50	95	TEAK WOOD	\$ 76,62	\$ 109,77	\$ 122,16
17	TEAK DINING CHAIR		KMK 017	40	50	90	TEAK WOOD	\$ 72,76	\$ 99,72	\$ 107,61
18	TEAK DINING CHAIR		KMK 018	40	50	90	TEAK WOOD	\$ 69,79	\$ 99,31	\$ 110,05
19	TEAK DINING ARM CHAIR		KMK 019	55	55	100	TEAK WOOD	\$ 85,63	\$ 116,34	\$ 125,94
20	TEAK DINING CHAIR		KMK 020	50	55	100	TEAK WOOD	\$ 78,37	\$ 107,52	\$ 116,10
21	TEAK DINING CHAIR		KMK 021	45	50	100	TEAK WOOD	\$ 82,68	\$ 113,65	\$ 122,87
22	TEAK DINING ARM CHAIR		KMK 022	55	50	100	TEAK WOOD	\$ 90,14	\$ 122,80	\$ 133,11
23	CLASSIC DINING ARM CHAIR		KMK 023	60	65	105	MAHOGANY	\$ 143,33	\$ 174,93	\$ 183,35











24	CLASSIC DINING ARM CHAIR		KMK 024	60	66	100	MAHOGANY	\$ 134,56	\$ 164,25	\$ 171,62
25	TEAK DINING CHAIR		KMK 025	40	55	90	TEAK WOOD	\$ 41,54	\$ 59,26	\$ 65,94
26	CLASSIC DINING ARM CHAIR		KMK 026	60	65	90	MAHOGANY	\$ 80,74	\$ 97,12	\$ 103,96
27	CLASSIC DINING CHAIR		KMK 027	50	65	90	MAHOGANY	\$ 64,35	\$ 78,63	\$ 83,58
28	CLASSIC DINING ARM CHAIR		KMK 028	50	65	90	MAHOGANY	\$ 78,40	\$ 94,22	\$ 100,96
29	CLASSIC DINING CHAIR		KMK 029	60	65	90	MAHOGANY	\$ 63,18	\$ 77,23	\$ 81,96
30	CLASSIC DINING ARM CHAIR		KMK 030	55	60	110	MAHOGANY	\$ 110,57	\$ 134,15	\$ 141,94
31	CLASSIC DINING CHAIR		KMK 031	45	60	110	MAHOGANY	\$ 92,44	\$ 113,50	\$ 119,29
32	CLASSIC DINING ARM CHAIR		KMK 032	60	65	105	MAHOGANY	\$ 120,52	\$ 145,97	\$ 155,97
33	CLASSIC DINING ARM CHAIR		KMK 033	65	65	110	MAHOGANY	\$ 114,08	\$ 138,22	\$ 147,17
34	CLASSIC DINING ARM CHAIR		KMK 034	55	65	110	MAHOGANY	\$ 80,15	\$ 96,53	\$ 102,85
35	TEAK DINING CHAIR		KMK 035	40	50	90	TEAK WOOD	\$ 62,34	\$ 88,28	\$ 97,55

36	TEAK DINING ARM CHAIR		KMK 036	50	55	95	TEAK WOOD	\$ 89,80	\$ 126,68	\$ 140,70
37	TEAK DINING CHAIR		KMK 037	50	55	95	TEAK WOOD	\$ 75,03	\$ 105,63	\$ 116,17
38	CLASSIC DINING CHAIR		KMK 038	50	70	100	MAHOGANY	\$ 77,81	\$ 95,65	\$ 99,87
39	CLASSIC DINING ARM CHAIR		KMK 039	50	70	100	MAHOGANY	\$ 90,68	\$ 109,84	\$ 115,63
40	CLASSIC DINING CHAIR		KMK 040	45	60	90	MAHOGANY	\$ 63,18	\$ 77,23	\$ 81,96
41	CLASSIC DINING ARM CHAIR		KMK 041	50	60	90	MAHOGANY	\$ 70,20	\$ 84,39	\$ 89,66
42	CLASSIC DINING CHAIR		KMK 042	55	65	105	MAHOGANY	\$ 78,40	\$ 95,65	\$ 102,50
43	CLASSIC DINING CHAIR		KMK 043	70	70	85	MAHOGANY	\$ 86,00	\$ 104,22	\$ 109,17
44	CLASSIC DINING ARM CHAIR		KMK 044	65	70	95	MAHOGANY	\$ 90,68	\$ 109,84	\$ 115,63
45	CLASSIC DINING CHAIR		KMK 045	60	66	100	MAHOGANY	\$ 78,98	\$ 96,94	\$ 101,79
46	CLASSIC DINING ARM CHAIR		KMK 046	60	66	100	MAHOGANY	\$ 91,27	\$ 110,54	\$ 116,44
47	CLASSIC DINING CHAIR		KMK 047	60	65	120	MAHOGANY	\$ 184,29	\$ 224,66	\$ 238,35

48	CLASSIC DINING ARM CHAIR		KMK 048	60	65	105	MAHOGANY	\$	121,10	\$	147,81	\$	153,81
49	CLASSIC DINING CHAIR		KMK 049	60	66	100	MAHOGANY	\$	71,96	\$	88,05	\$	93,31
50	CLASSIC DINING ARM CHAIR		KMK 050	60	66	90	MAHOGANY	\$	84,83	\$	102,24	\$	109,08
51	CLASSIC DINING CHAIR		KMK 051	60	66	100	MAHOGANY	\$	80,15	\$	98,46	\$	103,10
52	CLASSIC DINING ARM CHAIR		KMK 052	60	66	100	MAHOGANY	\$	92,44	\$	112,09	\$	117,67
53	CLASSIC DINING ARM CHAIR		KMK 053	55	65	85	MAHOGANY	\$	93,61	\$	113,21	\$	120,05
54	CLASSIC DINING ARM CHAIR		KMK 054	60	70	105	MAHOGANY	\$	128,71	\$	156,94	\$	164,31
55	CLASSIC DINING CHAIR		KMK 055	60	66	100	MAHOGANY	\$	74,89	\$	91,62	\$	97,20
56	CLASSIC DINING ARM CHAIR		KMK 056	60	66	100	MAHOGANY	\$	86,00	\$	103,70	\$	110,54
57	CLASSIC DINING ARM CHAIR		KMK 057	55	65	95	MAHOGANY	\$	73,72	\$	88,60	\$	94,50
58	CLASSIC DINING ARM CHAIR		KMK 058	45	55	70	MAHOGANY	\$	70,20	\$	96,97	\$	106,51
59	CLASSIC DINING ARM CHAIR		KMK 059	65	70	80	MAHOGANY	\$	88,93	\$	107,35	\$	114,20













60	CLASSIC DINING CHAIR		KMK 060	60	66	100	MAHOGANY	\$	80,15	\$	98,46	\$	103,10
61	CLASSIC DINING ARM CHAIR		KMK 061	65	66	100	MAHOGANY	\$	89,51	\$	108,44	\$	114,02
62	CLASSIC DINING CHAIR		KMK 062	55	60	105	MAHOGANY	\$	61,43	\$	74,97	\$	79,92
63	CLASSIC DINING ARM CHAIR		KMK 063	60	60	105	MAHOGANY	\$	70,79	\$	84,95	\$	90,85
64	CLASSIC DINING CHAIR		KMK 064	55	60	105	MAHOGANY	\$	77,23	\$	94,43	\$	100,43
65	CLASSIC DINING CHAIR		KMK 065	50	60	110	MAHOGANY	\$	93,61	\$	112,91	\$	120,81
66	CLASSIC DINING CHAIR		KMK 066	55	60	105	MAHOGANY	\$	70,79	\$	86,67	\$	91,62
67	CLASSIC DINING CHAIR		KMK 067	55	60	105	MAHOGANY	\$	64,35	\$	78,63	\$	83,58
68	CLASSIC DINING ARM CHAIR		KMK 068	60	60	105	MAHOGANY	\$	73,72	\$	88,60	\$	94,50
69	CLASSIC DINING CHAIR		KMK 069	55	60	105	MAHOGANY	\$	66,69	\$	81,47	\$	86,73
70	CLASSIC DINING CHAIR		KMK 070	60	65	105	MAHOGANY	\$	86,00	\$	105,78	\$	110,41
71	CLASSIC DINING ARM CHAIR		KMK 071	60	65	105	MAHOGANY	\$	70,20	\$	84,39	\$	89,66


72	CLASSIC DINING CHAIR		KMK 072	50	65	105	MAHOGANY	\$	60,26	\$	73,72	\$	77,93
73	CLASSIC DINING ARM CHAIR		KMK 073	60	60	105	MAHOGANY	\$	82,49	\$	99,28	\$	106,23
74	CLASSIC DINING CHAIR		KMK 074	55	60	105	MAHOGANY	\$	68,45	\$	83,66	\$	88,93
75	CLASSIC DINING ARM CHAIR		KMK 075	60	60	105	MAHOGANY	\$	75,47	\$	90,77	\$	96,77
76	CLASSIC DINING CHAIR		KMK 076	55	60	105	MAHOGANY	\$	63,77	\$	77,96	\$	82,70
77	CLASSIC DINING ARM CHAIR		KMK 077	60	60	105	MAHOGANY	\$	74,30	\$	89,36	\$	95,16
78	CLASSIC DINING CHAIR		KMK 078	50	60	110	MAHOGANY	\$	87,76	\$	105,75	\$	113,12
79	CLASSIC DINING CHAIR		KMK 079	55	60	105	MAHOGANY	\$	64,35	\$	78,72	\$	83,35
80	CLASSIC DINING ARM CHAIR		KMK 080	55	60	100	MAHOGANY	\$	84,83	\$	102,24	\$	109,08
81	CLASSIC DINING CHAIR		KMK 081	50	60	100	MAHOGANY	\$	73,13	\$	89,42	\$	95,00
82	CLASSIC DINING CHAIR		KMK 082	50	65	100	MAHOGANY	\$	76,06	\$	93,46	\$	97,67
83	CLASSIC DINING CHAIR		KMK 083	45	55	100	MAHOGANY	\$	49,73	\$	60,41	\$	65,14

84	CLASSIC DINING CHAIR		KMK 084	45	55	100	MAHOGANY	\$	50,90	\$	61,81	\$	66,76
85	CLASSIC DINING CHAIR		KMK 085	45	55	105	MAHOGANY	\$	77,81	\$	95,57	\$	100,09
86	CLASSIC DINING CHAIR		KMK 086	45	55	100	MAHOGANY	\$	69,03	\$	84,83	\$	88,52
87	CLASSIC DINING CHAIR		KMK 087	45	55	100	MAHOGANY	\$	78,40	\$	96,27	\$	100,90
88	CLASSIC DINING CHAIR		KMK 088	40	55	100	MAHOGANY	\$	50,31	\$	61,11	\$	65,95
89	TEAK DINING CHAIR		KMK 089	50	55	80	TEAK WOOD	\$	72,46	\$	102,11	\$	112,38
90	TEAK DINING CHAIR		KMK 090	45	50	110	TEAK WOOD	\$	40,95	\$	58,53	\$	65,21
91	TEAK DINING ARM CHAIR		KMK 091	50	55	95	TEAK WOOD	\$	79,44	\$	114,30	\$	127,80
92	TEAK DINING CHAIR		KMK 092	45	55	95	TEAK WOOD	\$	64,42	\$	92,79	\$	103,68
93	TEAK DINING CHAIR		KMK 093	45	55	95	TEAK WOOD	\$	66,84	\$	95,39	\$	105,93
94	TEAK DINING ARM CHAIR		KMK 094	50	55	95	TEAK WOOD	\$	83,95	\$	120,54	\$	134,55
95	TEAK DINING CHAIR		KMK 095	45	56	95	TEAK WOOD	\$	66,80	\$	91,33	\$	98,42

96	TEAK DINING ARM CHAIR		KMK 096	45	56	95	TEAK WOOD	\$	77,21	\$	106,23	\$	115,19
97	TEAK DINING ARM CHAIR		KMK 097	48	55	95	TEAK WOOD	\$	80,75	\$	111,99	\$	122,11
98	TEAK DINING CHAIR		KMK 098	40	50	90	TEAK WOOD	\$	60,57	\$	90,06	\$	102,75
99	TEAK DINING ARM CHAIR		KMK 099	50	55	135	TEAK WOOD	\$	106,39	\$	153,79	\$	172,26
100	TEAK DINING CHAIR		KMK 100	45	55	135	TEAK WOOD	\$	93,26	\$	133,50	\$	148,64
101	TEAK DINING CHAIR		KMK 101	40	50	90	TEAK WOOD	\$	60,85	\$	90,52	\$	103,30
102	TEAK DINING CHAIR		KMK 102	40	50	95	TEAK WOOD	\$	50,65	\$	73,89	\$	83,34
103	TEAK DINING CHAIR		KMK 103	45	55	95	TEAK WOOD	\$	81,32	\$	111,44	\$	120,21
104	TEAK DINING ARM CHAIR		KMK 104	50	55	95	TEAK WOOD	\$	89,51	\$	122,94	\$	133,05
105	TEAK DINING ARM CHAIR		KMK 105	58	48	115	TEAK WOOD	\$	105,31	\$	152,02	\$	170,14
106	TEAK DINING ARM CHAIR		KMK 106	57	60	115	TEAK WOOD	\$	111,74	\$	160,29	\$	178,60
107	TEAK DINING ARM CHAIR		KMK 107	57	60	115	TEAK WOOD	\$	117,59	\$	167,60	\$	185,91

108	TEAK DINING CHAIR		KMK 108	50	50	85	TEAK WOOD	\$ 58,83	\$ 87,22	\$ 99,34
109	TEAK DINING CHAIR		KMK 109	58	48	115	TEAK WOOD	\$ 90,68	\$ 129,30	\$ 143,60
110	TEAK DINING CHAIR		KMK 110	45	50	90	TEAK WOOD	\$ 58,50	\$ 86,70	\$ 98,71
111	TEAK DINING CHAIR		KMK 111	58	56	87	TEAK WOOD	\$ 81,91	\$ 112,17	\$ 120,94
112	TEAK DINING ARM CHAIR		KMK 112	55	50	85	TEAK WOOD	\$ 67,66	\$ 100,66	\$ 115,09
113	TEAK DINING ARM CHAIR		KMK 113	58	56	87	TEAK WOOD	\$ 91,85	\$ 126,76	\$ 137,63
114	TEAK DINING ARM CHAIR		KMK 114	55	55	97	TEAK WOOD	\$ 78,98	\$ 114,67	\$ 128,97
115	TEAK DINING CHAIR		KMK 115	45	55	95	TEAK WOOD	\$ 61,71	\$ 91,92	\$ 104,98
116	TEAK DINING ARM CHAIR		KMK 116	50	55	95	TEAK WOOD	\$ 67,61	\$ 99,47	\$ 112,92
117	TEAK DINING CHAIR		KMK 117	50	55	115	TEAK WOOD	\$ 80,43	\$ 115,54	\$ 128,79
118	TEAK DINING ARM CHAIR		KMK 118	50	55	115	TEAK WOOD	\$ 92,76	\$ 132,91	\$ 148,08
119	TEAK DINING CHAIR		KMK 119	50	55	110	TEAK WOOD	\$ 57,33	\$ 81,24	\$ 89,82

120	TEAK DINING CHAIR		KMK 120	40	50	80	TEAK WOOD	\$ 47,41	\$ 68,61	\$ 77,01
121	TEAK DINING CHAIR		KMK 121	40	50	90	TEAK WOOD	\$ 67,94	\$ 94,97	\$ 103,96
122	CLASSIC DINING ARM CHAIR		KMK 122	45	50	90	MAHOGANY	\$ 63,77	\$ 77,52	\$ 82,78
123	CLASSIC DINING CHAIR		KMK 123	45	45	90	MAHOGANY	\$ 57,33	\$ 69,92	\$ 74,65
124	CLASSIC DINING ARM CHAIR		KMK 124	55	55	110	MAHOGANY	\$ 75,47	\$ 91,88	\$ 98,09
125	CLASSIC DINING CHAIR		KMK 125	50	55	110	MAHOGANY	\$ 63,77	\$ 77,96	\$ 82,70
126	CLASSIC DINING ARM CHAIR		KMK 126	50	55	105	MAHOGANY	\$ 88,34	\$ 108,18	\$ 113,65
127	CLASSIC DINING CHAIR		KMK 127	45	55	105	MAHOGANY	\$ 79,57	\$ 97,76	\$ 102,29
128	CLASSIC DINING ARM CHAIR		KMK 128	45	50	95	MAHOGANY	\$ 91,85	\$ 113,00	\$ 115,54
129	CLASSIC DINING ARM CHAIR		KMK 129	45	50	95	MAHOGANY	\$ 97,12	\$ 119,38	\$ 122,44
130	CLASSIC DINING ARM CHAIR		KMK 130	50	55	100	MAHOGANY	\$ 103,55	\$ 127,25	\$ 130,70
131	CLASSIC DINING ARM CHAIR		KMK 131	50	55	95	MAHOGANY	\$ 93,02	\$ 114,46	\$ 116,96

132	CLASSIC DINING ARM CHAIR		KMK 132	45	50	100	MAHOGANY	\$ 90,68	\$ 111,63	\$ 113,90
-----	--------------------------	---	---------	----	----	-----	----------	----------	-----------	-----------